

SALALAH/Salalah
OMAN
RWY 07

DAXAM
D40.8/R-070 SLL

SID DAXAM 1P/DAXAM 1T
Initial clearance to 10000 FT and wait for further clearance.

SID MUTVA 1P
Initial clearance to 10000 FT and wait for further clearance.

SILTA 1P
Initial clearance to 10000 FT and wait for further clearance.

LADAR 1P
Initial clearance to 10000 FT and wait for further clearance.

INITIAL CLIMB
Climb on runway heading to D1.4/R-070 SLL, then

SID	ROUTING
DAXAM 1P	proceed on R-070 SLL to D9.5/R-070 SLL at or above 3200. Proceed to DAXAM.
DAXAM 1T	turn RIGHT to intercept and follow R-099 SLL to D25.0/R-099 SLL, then turn LEFT to follow 27 DME ARC SLL to R-075 SLL, then turn RIGHT to intercept and follow R-070 SLL to DAXAM.
MUTVA 1P	turn RIGHT to intercept and follow R-111 SLL to MUTVA.
SILTA 1P	turn RIGHT to intercept and follow R-111 SLL to D13.0/R-111 SLL, then turn LEFT to intercept and follow R-160 SLL to SILTA.
LADAR 1P	turn RIGHT to intercept and follow R-111 SLL to D13.0/R-111 SLL, then turn RIGHT to follow 15 DME ARC SLL to R-235 SLL, then turn LEFT to intercept and follow R-243 SLL to LADAR.